

## Application Instructions

1. Apply to a clean, dry surface. Cleaning with alcohol is recommended.
2. Slowly remove decal backing.
3. Apply to your clean, dry surface using vinyl transfer layer. Be sure to position to level and straightness.
4. Use fingers to press onto surface across the decal paying attention to the ridge in the spoiler first.
5. **SLOWLY** remove release liner at a sharp angle being sure not to pull decal off of surface. This may take some patience and you may need to 'assist' the decal sticking depending on the type of surface you are applying to.